



HOW TO DESCALE HOT WATER URN

1. Fill your dispenser with water and let it reach the required temperature
2. Add your chosen descale and leave for the required time as instructed on packing.
3. When done, drain the dispenser and flush the system before using as normal